






BUTTONS




Battery:CR2025


b ALARM



c STOPWATCH





d DUAL TIME




MODESELECTION



a TIMEKEEPING





BACKLIGHT




MODE AUSWAHL




a Zeitmessung



Hintergrundbeleuchtung





TASTEN




Batterie:CR2025



b Alarm



c Stoppuhr





d Dual Zeit




SELECCIÓN DE MODO




a Cronometraje



LUZ TRASERA




Botones




Battery:CR2025


b ALARMA



c Cronómetro





d TIEMPO DOBLE




SELEÇÃO DE MODO




a Contagem



LUZ DO FUNDO




BOTÕES




Bateria:CR2025


b ALARME



c CRONÔMETRO




d TEMPO DUPLO






SELECTION MODE




a Chronométrage




Affichage de date, mois, l'année




Réglement des temps




LUMIÈRE ARRIÈRE




BOUTONS




b Alarm



c CHRONOMÈTRE



d Duitemps



ВЫБОР МОДЕЛИ




a ХРОНОМЕТРИРОВАНИЕ




Индикация года, месяца, даты




Установка времени




ПОДСВЕТ




КНОПКИ





b СИГНАЛИЗАЦИЯ




c СЕКУНДОМЕР




d ДВОЙНОЕ ВРЕМЯ



MODALITÀ DI SELEZIONE




a Cronometraggio




Display: Anno, Mese, Data




Tempo Impostazione




Retroilluminazione




TASTI




b ALLARME




c CRONOMETRO




d DUALTIME



模式選擇




a 時間




年、月、日顯示




時間設置




冷光




按鍵功能



b 鬧鈴



c 跑表



d 第二時間

